

2019 Winch Preflight

1. Pull out the rope and inspect the condition
2. Inspect the Parachute and other accessories including the weak link
3. Fill the winch with fuel, operate with no less than ½ full tank. 100LL Avgas recommended, not required.
4. Check the oil quantity in the winch. 10w-30 or 10w-40 automotive oil required
5. Check the radiator for anti-freeze level
6. Make sure the winch is secured to a vehicle and chocked on both wheels
7. Walk around the winch and inspect for general condition.
8. Install the Radio and antenna. Use of a Aviation headset with microphone and push to talk is strongly recommended
9. Pump the throttle 3-5 strokes to prime the engine
10. Start the engine, ensure oil pressure
11. Operate the winch between 170°F and 220°F water temp
12. Comply with the operations manual Written by Jim Martin